Corso di Architettura dei Sistemi a Microprocessore

Architetture SIMD



Luigi Coppolino



The Fault and Intrusion Tolerant NEtworked SystemS (FITNESS) Research Group http://www.fitnesslab.eu/



Contact info


Prof. Luigi Coppolino luigi.coppolino@uniparthenope.it

Università degli Studi di Napoli "Parthenope" Dipartimento di Ingegneria

Centro Direzionale di Napoli, Isola C4 V Piano lato SUD - Stanza n. 512

> Tel: +39-081-5476702 Fax: +39-081-5476777









Textbook: Chapter 11





Chapter Outline

- Multithreading
- Vector (SIMD) processing
- Multimedia Extensions (x86)
- > GPU





Hardware Multithreading

- A process is a program and its current state (e.g., a Web browser or a word processor)
- Each process has a corresponding *thread*, which is an independent path of execution
- Encompasses state in PC and other registers
- Operating system (OS) enables multitasking by time slicing and context switching of threads
- For efficient handling of multiple threads, processors can use hardware multithreading





Hardware Multithreading

- Hardware includes multiple sets of registers, including multiple program counters
- Each set of registers is for a different thread
- No time is wasted saving/restoring registers
- Context switch simply involves changing a hardware pointer to active set of registers
- Coarse-grained multithreading: switch on long-latency events, such as cache misses
- Fine-grained or interleaved: switch every cycle





Vector (SIMD) Processing

- > A *vector* is an array of consecutive elements
- Loops process arrays one element at a time
- Implementing a processor with multiple ALUs enables multiple operations simultaneously
- Requires that programs have data parallelism, which means operations are independent
- Use single-instruction multiple-data (SIMD) or vector instructions and data in vector registers





Vectorization

- Vector length L for elements per register and number of parallel operations per instruction
- Use this parameter to vectorize loop code
- Involves using vector (SIMD) instructions to reduce the number of instructions executed
- A vectorizing compiler can perform analysis to detect data parallelism for transformation
- Each pass of vectorized loop does L operations to ideally reduce instruction count by factor L





Vector Registers

- Vector Instructions data are held in Vector Registers
 - Each Vector Register can store more data elements
 - The number of elements stored in a Vector Register is said Vector Length
- Intel IA-32
 - 128 bit length Vector Regisers
 - \circ L can be from 2 to 16 => data from 64 to 8 bits





for (i = 0; i < N; i++)A[i] = B[i] + C[i];

(a) A C-language loop to add vector elements

	Move	R5, #N	R5 is the loop counter.
LOOP:	Load	R6, (R3)	R3 points to an element in array B.
	Load	R7, (R4)	R4 points to an element in array C.
	Add	R6, R6, R7	Add a pair of elements from the arrays.
	Store	R6, (R2)	R2 points to an element in array A.
	Add	R2, R2, #4	Increment the three array pointers.
	Add	R3, R3, #4	
	Add	R4, R4, #4	
	Subtract	R5, R5, #1	Decrement the loop counter.
	Branch_if_[R5]>0	LOOP	Repeat the loop if not finished.

(b) Assembly-language instructions for the loop

http://www.fitnesslab.eu/



	Move	R5, #N	R5 counts the number of elements to process.
LOOP:	VectorLoad.S	V0, (R3)	Load <i>L</i> elements from array B.
	VectorLoad.S	V1, (R4)	Load L elements from array C.
	VectorAdd.S	V0, V0, V1	Add L pairs of elements from the arrays.
	VectorStore.S	V0, (R2)	Store <i>L</i> elements to array A.
	Add	R2, R2, #4*L	Increment the array pointers by L words.
	Add	R3, R3, #4*L	
	Add	R4, R4, #4*L	
	Subtract	R5, R5, #L	Decrement the loop counter by L .
	Branch_if_[R5]>0	LOOP	Repeat the loop if not finished.

(c) Vectorized form of the loop



Streaming SIMD Extensions (SSE)

- Introduced by Intel with Pentium III
 - It is an evolution of the MMX technology previously implemented by Intel
 - SSE was introduced as a reply to the AMD 3DNow! Implementation of the MMX technology
 - Later AMD implemented the SSE instruction set
- Is a SIMD extention of the Pentium ISA
- SSE makes use of 8 vectored registers (128 bits) for floating point operations
 - SSE2 extends the usage of vectored registers to integer operations
- With SSE2 it was possible use the vector registers to store:
 - two 64-bit double-precision floating point numbers or
 - o two 64-bit integers or
 - o four 32-bit integers or
 - o eight 16-bit short integers or
 - o sixteen 8-bit bytes or characters.
- Pentium IV introduced SSE3 and in its last implementation SSE4





Multimedia Extensions Vs Vector Processing

- SSE vector registers are typically much shorter than vector processors registers
- The size of the operands is encodend in the opcode for SSE while it is in a separate register for VPs
- A vector is loaded with consecutive memory locations in SSE while this is not a constraint for VPs
 - As an example it can be loaded with elements at a fixed distance





Graphics Processing Units (GPUs)

- Demand for high-resolution, 3-D graphics has driven development of powerful GPU chips
- Graphics applications have data parallelism in floating-point calculations and other tasks
- Large GPUs have hundreds of simple cores
- General vector processing possible with cores executing the same program on different data
- Programming support: CUDA C and OpenCL



